Installation Instructions: Apache Offroad- Heavy Duty Dual Jerry Can Mount

Contents:
1 Dual Jerry Can Mount
4 Allen head screws
4 locking washers
4 crossbar nuts w/ ball bearing

Tools Needed:
Ladder
Towel or Piece of cardboard (Use as needed to protect your paint)
5/32 Allen wrench

Attention:
Apache Offroad is not responsible for damages to the vehicle or injuries resulting from installing our products on a vehicle. Professional Installation and/or assistance is recommended for all installations. Please remember to wear eye protection.

Time Required: 30 min
People required: 1

1) If you have not done so already, install your Apache LoPro Rack.
2) Our crossbar nuts are able to be inserted any where along the crossbar. Slide two nuts into each bar and position them at the approximate width of the Jerry Can Mount. (Nuts will need to be slid in at an angle) (The ball bearing is spring loaded and will hold the nut in place while installing the mount)
3) Position the Dual Jerry Can Mount over the inserted nuts.
4) Install locking nuts on each screw
5) Tighten the screws, be sure to tighten the screws until the lock washer is fully compressed and the screws are tight.
6) Load your Jerry Cans
7) Apply a lock or clip to keep the carrier closed (Not included)